


H-53 Heavy Duty Ball Bearing Slide - Installation Instructions


Installation Dimensions



Slide Mounting Positions on the Cabinet







NL - Nominal slide length

LW - Internal cabinet width

SKW - Internal drawer width

SKL - Drawer length